

Driver Setup (vista 64)

1. Login vista64 as Administrator.
2. Execute the "Disable Integrity Checks.bat" file under the current directory.
3. Reboot your system.
4. Connect your machine to USB port, and setup the driver follow the system's prompt.